

787mm

749mm

Stylish®

TOPMOUNT

Countertop

Silicone

Granite Kitchen Sink

UNDERMOUNT

Countertop

Bolt Plate

Nut

Bolt

Clip

Sink Pocket

Granite Kitchen Sink

S-832W

CANMORE

1. Cut out countertop using this template.

2. FOR UNDERMOUNT INSTALLATION ONLY: Check sink pocket positions, and determine where to glue the bolt plates. Stick the bolt plates underneath the countertop, then let the bracket adhesive to cure before applying weight to the bolt plate.

3. Apply a bead of silicone evenly along edge on underside of countertop or sink.

4. Position and align sink over opening. Press sink onto silicone seal.

5. FOR UNDERMOUNT INSTALLATION ONLY: After re-checking alignment, tighten clip brackets.

6. Remove excess of silicone.

7. It is recommended to hold sink in place using other means for at least 24 hours to allow the silicone and adhesive to cure.

⚠️ **Note:** THIS TEMPLATE IS ONLY A GUIDE. ACTUAL SINK SHOULD BE PRESENT TO ENSURE PERFECT CUT OUT.

⚠️ **Hint:** After silicone cures, wipe inside edge with denatured alcohol. This smooths out any rough areas.

@stylish.international.inc

Customer Service

1-855-789-5352

CONÇU AU CANADA

DESIGNÉ EN CANADA

DXF file and installation instructions available to be downloaded in our website at

www.stylishkb.com

394mm

432mm